

SALADMASTER®

Cleaning the Cookware

Before First Use

Wash your new Saladmaster cookware to remove all traces of any manufacturing oils and polishing compounds prior to first use.

1. Prepare warm, soapy water in kitchen sink.
2. Add 1 cup (250 ml) of vinegar per one gallon (3.8L) of water.
3. Wash each piece of cookware, including detachable handles, in water solution.
4. Rinse in clear, warm water.
5. Dry thoroughly with a clean, soft towel.



use soft brush or paper towel



SALADMASTER®

Cleaning the Cookware

Daily Use Cleaning

Cleaning your cookware on a normal basis after cooking is easy with Saladmaster.

1. Remove detachable handles.
2. Wash cookware and handles in warm, soapy water.
3. Rinse in clear, warm water.
4. Dry thoroughly with a clean, soft towel.

- Avoid using abrasive cleaning tools and cleansers on the high-polish surfaces. This can impact the look and dull the finish over time.

- As the Vapo-Valve™ is precision cut to integrate into the cover, be careful when cleaning or drying the edges of the valve.



Alternatively, your cookware can also be placed in the dishwasher.

1. Remove (unscrew) knob from cover prior to placing in dishwasher.

- Cleaning knob in dishwasher can impact the look and dull the finish over time

2. Do not use high temperature setting when using dishwasher. We recommend using below standard temperature.

3. Avoid using abrasive dishwasher detergents. It can cause the rim to become rough.

- We recommend only hand washing the detachable handles and cover knob. Avoid using abrasive cleaning tools or cleansers.



SALADMASTER®

Cleaning the Cookware

For Stubborn Stains or Stuck-on Food

Use our Saladmaster Powdered Cleaner when you have stubborn stains or stuck-on food that remain after normal cleaning.

1. Rinse pan with warm water.
2. Sprinkle the powdered cleaner on the inside of the pan.
3. Using a damp paper towel, rub the powdered cleaner across the surface in circular motions creating a paste.



- Avoid using abrasive cleaning tools and cleansers on the high-polish surfaces. This can impact the look and dull the finish over time.

4. Wash well in warm, soapy water to remove all cleanser.
5. Dry with a clean towel, soft towel.
6. Rinse and dry with a clean, soft towel.